

Custom metering centres



CUSTOM METERING CENTRES



E-Contacts:
asiakaspalvelu@pok.fi
etunimi.sukunimi@pok.fi
www.pok.fi


Phone numbers:
Vaihde: 010 5727 501
Myynti: 010 5727 520
Suunnittelu: 010 5727 530

VAT:
0306687-3
FI03066873

POK[®]

CUSTOM METERING CENTRES

SSTL number	Name	Product description	In	Installation
R10067	SMK840P/U/42, Mittauskeskus uppo/pinta FE	Asiakaskohtainen malli	-	Pinta/Uppo
R10068	SMK1120P/U/84, Mittauskeskus uppo/pinta FE	Asiakaskohtainen malli	-	Pinta/Uppo
R10147	RKS750U/22, Mittauskeskus uppo FE	Asiakaskohtainen malli	-	
R10157	RKS750P/22, Mittauskeskus pinta FE	Asiakaskohtainen malli	-	Surface
R10180	OKK1500PU/72, Mittauskeskus-data pinta/uppo FE	Asiakaskohtainen malli	-	Pinta/Uppo



Technical details

Ue (V)	230/400	Breaker 1-pole C10	-
In (A)	-	Breaker 1-pole B16	-
IP	20	Breaker 1-pole C16	-
fn		Breaker 1-pole C20	-
Icw	<5 kA	Breaker 3-pole C16	-
Material	Ku-Si		-
Main switch (A)	-		-
Breaker 1-pole C6	-		1
Breaker 1-pole B10	-	Installation	Pinta/Uppo





Technical details

Ue (V)	230/400	Breaker 1-pole C10	-
In (A)	-	Breaker 1-pole B16	-
IP	20	Breaker 1-pole C16	-
fn		Breaker 1-pole C20	-
Icw	<5 kA	Breaker 3-pole C16	-
Material	Ku-Si		-
Main switch (A)	-		1
Breaker 1-pole C6	-	Installation	Pinta/Uppo
Breaker 1-pole B10	-		





Technical details

Ue (V)	230/400	Breaker 1-pole B16	-
In (A)	-	Breaker 1-pole C16	-
IP	20	Breaker 1-pole C20	-
fn		Breaker 3-pole C16	-
Icw	<5 kA		-
Material	Ku-Si		-
Main switch (A)	-		1
Breaker 1-pole C6	-		237 x 714
Breaker 1-pole B10	-	Installation	
Breaker 1-pole C10	-		





Technical details

Ue (V)	230/400	Breaker 1-pole C10	-
In (A)	-	Breaker 1-pole B16	-
IP	20	Breaker 1-pole C16	-
fn		Breaker 1-pole C20	-
Icw	<5 kA	Breaker 3-pole C16	-
Material	Ku-Si		-
Main switch (A)	-		-
Breaker 1-pole C6	-	Installation	Surface
Breaker 1-pole B10	-		





Technical details

Ue (V)	230/400	Breaker 1-pole B16	-
In (A)	-	Breaker 1-pole C16	-
IP	30	Breaker 1-pole C20	-
fn		Breaker 3-pole C16	-
Icw	<5 kA		-
Material	Ku-Si		-
Main switch (A)	-		1
Breaker 1-pole C6	-	RJ -connector	
Breaker 1-pole B10	-	Installation	Pinta/Uppo
Breaker 1-pole C10	-		

