





## **Product info**

In the ITP data group centres, the IT and electricity distribution spaces are located on top of each other. The side of the centre has a cable chute by the IT space for the wiring of the electricity distribution section. This makes it easy to connect a feed cable from the bottom. The IT space can be equipped with a wide variety of fittings, which enable several different uses. Available for both surface and flush mounting. The surface-mounted model contains the necessary feed-through flanges and a fixed back plate. When flush-mounted, the centre only rises 4mm above the wall surface!

## **Technical details**

Ue (V)	230/400	Breaker 1-pole C10	-
In (A)	-	Breaker 1-pole B16	-
IP	20	Breaker 1-pole C16	-
fn		Breaker 1-pole C20	-
Icw	<5 kA	Breaker 3-pole C16	-
Material	Ku-Si		-
Main switch (A)	-		-
Breaker 1-pole C6	-	RJ -connector	
Breaker 1-pole B10	-	Installation	Surface



